

GUY-VISE - AUTOMATIC DEAD ENDS

Instructions for Use


The following instructions apply to product codes:
GV04, GV06, GV08, GV10 and GV12



Use only with 1770N/mm² or 1960/mm² grade 6x19wsc, 6x36wsc, 7x19 or 7x36 construction steel wire rope - **FOR STATIC LOADS ONLY**



There are three components; the bail, body and collar



Firstly compress the bail and insert into the collar




When done it should look like this



Now insert the body into the collar



Then ensuring the rope end is clean cut, insert into the body



Now push the rope through the jaws and adjust as required